



INSTALLING A SERIAL PORT ON THE DTA310



J5 PINOUT
1 NOT USED (+3.3V DC)
2 Serial Out
3 Serial In
4 GND
5 GND



PARTS LIST

- 1 LM7805 (5V DC regulator)
- 1 DS275 (RS232 transceiver)
- 1 RS232 25-pin connector (female)